WASHER DRYER

INSTRUCTIONS MANUAL GB

GB

Contents

1. The new washing system	3
2. Safety warnings	4
3. Installation instructions	7
4. Description of controls	9
5. Washing instructions	13
6. Drying instructions	19
7. Cleaning and maintenance	21
8. Troubleshooting	24
9. Control panel symbols	26

This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment WEEE).
By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.
Disposal must be carried out in accordance with local environmental regulations for waste disposal.
For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

1. THE NEW WASHING SYSTEM

This new washer dryer is the outcome of years of research.
The leading-edge design and the quality of the production processes used to manufacture this product ensure it will give you many years of excellent service.
Its concept satisfies all current and future washing and drying requirements.
Its low water, power and detergent consumption help protect the environment and reduce running costs to a minimum.

Water and power consumption has been reduced in all programmes.
These results were achieved by means of a **special washing system** valid for all programmes and all fabrics.
The drum is fitted with three external vanes that keep the water constantly circulating, thereby offering intensive and uniform washing whilst consuming less water.
This ensures your laundry is washed and treated with utmost care.

The new washing system is so effective that normally dirty laundry can even be cleaned without a pre-wash cycle.
Washing times have also been reduced.
Pre-washing is only recommended for very dirty laundry.

Please read the operating instructions with care in order to take full advantage of all the features offered by this washer dryer.

Warning!
Please read all the instructions contained in this manual in order to understand how to operate this appliance correctly and safely.
This manual is divided into paragraphs which provide a step-by-step description of all the functions of the appliance. The instructions are easy to understand and are accompanied by detailed illustrations.
This manual provides a quick and easy reference for answering all your questions concerning the use of your new washer dryer.
Keep this manual near the machine for future consultation.
When selling or moving the appliance, make sure this manual remains with the machine.

2. SAFETY WARNINGS

Attention!
These warnings are given for safety reasons.
Please read them carefully before installing and using the appliance.

This manual forms an integral part of the appliance and must therefore be kept intact together with the machine. Before using the appliance, carefully read all the instructions contained in this manual. Installation must be performed by a qualified technician in compliance with the regulations in force. It has been designed for domestic use and complies with EEC Directives 72/23, 89/336 (including 92/31 and 93/68) currently in force. The appliance is designed for the following purpose: washing and drying linen or fabrics declared by their manufacturers to be suitable for machine washing by means of an appropriate symbol. Any other use shall be considered improper. **The manufacturer declines all responsibility for uses other than those described above.**

The name plate featuring the technical data, serial number and markings is visibly positioned on the inner edge of the door. **This name plate must never be removed.**

Do not leaving discarded packaging materials unsupervised within the home. Separate the various packaging materials and take them to the nearest sorted waste collection centre.

The electrical and plumbing work require to install the appliance may only be performed by qualified technicians.

The appliance must be provided with an earth connection in accordance with the electrical safety regulations in force. **The manufacturer declines all responsibility for damage to persons or property resulting from failure to earth the appliance or from a defective earth connection.**
If the appliance is not connected to the electrical power supply by means of a plug, it is necessary to install an isolation switch with a contact opening gap of at least 3 mm.

The plug on the power cord and the corresponding socket must be of the same type and must conform to the regulations in force. Check that the voltage and frequency of the electrical power supply match the ratings on the name plate. Avoid using adaptors or shunt connections. Never unplug the appliance by pulling the power cord.

The machine is only disconnected from the electrical power supply if the plug has been removed from the socket or if the general switch has been turned off. After installation, the plug must remain accessible.

The appliance must always be connected to the water supply with new hoses (supplied with the appliance). Old hoses must never be reused.

Make sure the appliance does not lie on the power cord.

Before use, make sure the tub assembly has been released (see instructions).
If the tub assembly has not been released, it may damage the appliance or adjacent furniture or appliances during the spin cycle.

The washer dryer must never be used in vehicles, on ships or planes, or in special environmental conditions such as explosive or corrosive (powder, vapour and gas) atmospheres or near explosive and/or corrosive liquids.

Do not install the washer dryer in areas subject to frosting. Frozen pipes may burst under pressure.

Make sure that the drain hose is **securely attached to the basin and cannot move.**

If it is not securely fitted, the repulsive force of the water may detach it from the basin and cause **flooding.**
When attaching the hose to the basin, **make sure the water drains away rapidly and does not fill the basin up.**

Do not overload the appliance.

Never use detergents containing solvents or chemicals.
These may damage the machine and form poisonous fumes.
They may also catch fire and explode.

Do not wash petrol-soaked garments in the washer dryer. Make sure there are no inflammable items (e.g.: lighters, matches, etc.) in pockets before washing.
If volatile fluids have been used to clean garments, make sure that the substances have been removed before loading them in the washing machine.

Before loading garments for washing, make sure the pockets are empty, the buttons securely fixed and the zips closed.
Do not wash frayed or torn garments.

The glass of the door will heat up considerably when washing at elevated temperatures.

Make sure all the water has drained away before you open the door.
If water is present, only open the door after draining it. If in doubt, read the instructions manual.

The water in the machine is not drinkable!

Swallowing washing machine detergents can cause lesions in your mouth and throat.

Before removing laundry from the washer dryer, **make sure the drum has stopped moving.**

Always switch off the appliance after use to avoid wasting electricity.

Leave the door ajar between one wash and the next in order to keep the gasket in good condition.

Prolonged inactivity.
If the machine is left inactive for a long period: disconnect the machine from the electricity and water supplies and leave the door ajar to prevent bad smells from forming.

In the event of a fault, **never attempt to repair the machine yourself.** Disconnect the appliance from the electrical power supply and shut off the water tap. Then call a qualified technician. **Repairs may only be performed by qualified technicians.**
Repairs performed by unqualified people may be hazardous for users.

Obsolete appliances must be rendered unusable: make sure that the door cannot be closed (to prevent children from getting trapped inside while playing and risking their lives) and cut off the power cord after unplugging it.
The appliance must then be taken to a sorted waste collection centre.

This appliance is intended for use by adults.
Do not allow children to tamper with the controls or play with the washer dryer.
Do not allow children to approach the appliance while it is working.
Keep children away from the appliance.
Small animals or children may get inside the washer dryer.
Always check the inside of the drum before use and **do not allow children to play with the appliance.**
Packaging materials (plastic bags, polystyrene, metal profiles, etc.) must not be left within reach of children.
Keep children away from the machine when the door or detergent tray is open; the appliance may contain residues of detergent which can cause irreversible damage to the eyes, mouth and throat, as well as possible death by suffocation.

Important !
This appliance is easy to use.
In order to obtain the best results, however, read this manual with care and follow all the instructions before starting.
The manual gives instructions and useful advice on how to install, use and service the appliance correctly.

The manufacture declines all responsibility for damage to persons or property resulting from failure to observe the above precautions, from tampering with even just a single component of the appliance, or from the use of unoriginal spare parts.

For Great Britain only

Warning: this appliance must be earthed.



Fuse replacement
If the mains lead of this appliance is fitted with a **BS 1363A 13amp** fused plug, to change a fuse in this type of plug use an **A.S.T.A**. approved fuse to **BS 1362** type and proceed as follows:

1. Remove the fuse cover (**A**) and fuse (**B**)
2. Fit replacement 13A fuse into fuse cover
3. Refit both into plug

Important:
The fuse cover must be refitted when changing a fuse and if the fuse cover is lost the plug must not be used until a correct replacement is fitted.
Correct replacement are identified by the colour insert or the colour embossed in words on the base of the plug.
Replacement fuse covers are available from your local electrical store.

If the appliance is provided with a plugless supply cord:

- It is necessary to install in the fixed wiring an all-pole disconnection device having a gap between contacts of at least 3,5mm. After installation the disconnection device has to be easy to reach.
- The connection to the mains must be carried out by a qualified technician in accordance to the scheme shown below and the regulations in force



- In the event of damage to the supply cord, it has to be replaced by the manufacturer or an authorized technical service center in order to avoid any risk.

3. INSTALLATION INSTRUCTIONS

Important !
The appliance must be installed by a specialised technician according to current regulations.
This washer dryer is very heavy. Take care when lifting it.

3.1 UNPACKING

The inside of the machine comprises a moving assembly which is blocked for transport purposes by the screws (**A)** located at the rear of the washer dryer.

1. Release the assembly by removing these screws with a 13 mm wrench.
2. Remove the screws (**A)** and relative spacers (**B)** from the back of the washer dryer.
3. To prevent water from entering the machine or people from touching live components with their fingers, **close the four holes left open by the screws with the supplied plastic plugs (C).**



Attention!
- Do not turn the machine upside down and do not place it on its side.
- Keep all the components used to block the drum assembly as they will be needed if you decide to move the appliance in future.

3.2 POSITIONING AND LEVELLING

1. Place the appliance in the chosen position.

2. Carefully level the machine in all directions using a spirit level and adjusting the height of the feet if necessary. After adjusting the machine, lock the feet with the relative lock nuts.



The water inlet and drain hoses can be turned to the right or left depending on installation requirements.

Attention!
- **Carry out this operation carefully to prevent the washing machine from vibrating, generating noise or moving during operation.**
- **If the appliance is installed on a carpeted floor, ensure that the openings on its underside are not obstructed.**
- Make sure the washing machine does not touch walls, furniture, etc., while it is working.
- The appliance must not be installed behind a lockable door, or sliding door, or a door with hinge on the opposite side to the tumble dryer.

3.3 WATER SUPPLY CONNECTION



1. Check that inlet pressure lies between the following values: **50-900kPa**. For higher pressures, install a pressure reducer.
2. Connect the **cold water** inlet hose (**light blue** ring nut) to the cold water tap with a ¾ gas thread, taking care to screw it firmly into place in order to prevent leaks. The water inlet hose must not be bent or crushed and must not be replaced or cut.
3. If a **hot water** inlet is used, inlet water temperature must not exceed 60°C and the hose with the **red** ring nut must be connected to the hot water tap.

Attention!

- If the water pipe is new or has not been used for a long time, let a certain amount of water run before attaching the inlet hose. This stops any deposits of sand and other impurities from clogging the filters used by the machine to protect the water inlet valves.
- The new hose-set supplied with the appliance are to be used and the old hose-set should not be reused.

3.4 DRAIN CONNECTION

1. Insert the end of the drain hose into a drain pipe having an internal diameter of at least 4 cm and a height ranging between 50 and 90 cm, or attach it (using the relative curved plastic profile) to a basin or bath tub.



2. Always check that the end of the drain hose is securely attached in order to prevent the repulsive force of the water from moving it out of position.

Attention!

- Do not bend or obstruct the hose as this will reduce the flow of water.
- Any extensions to the drain hose must not exceed 1 metre, they must have the same internal diameter and must not be obstructed in any way.
- In no case may the end of the drain hose be submerged in water.

3.5 ELECTRICAL CONNECTION

Before fitting the plug into the socket, make sure that:

1. Input voltage matches that indicated on the name plate attached to the inner edge of the door.
2. The contactor, pressure relief valves, power line and socket are capable of withstanding the maximum rated power input indicated on the name plate.
3. The socket is compatible with the plug supplied with the machine without the need to fit multiple sockets, adaptors or extension leads that could cause overheating or burning.
   If the socket does not correspond to the supplied plug, replace the socket with one of a suitable type.

Attention

- The plug must be accessible after installation.
- **The appliance must be earthed.** Plug the machine into a socket fitted with an efficient earth connection.

The manufacturer declines all responsibility for damage to persons or property resulting from failure to earth the appliance or from a defective earth connection. Correct electrical connections guarantee maximum safety.

- This appliance complies with EEC directive 89/336 of 3.5.89 (modified by EEC directive 92/31) relative to the elimination of radio interference.
- If the power cord is damaged, only replace it with an original spare part available from our service department.
- **Do not insert/remove the plug from the socket if your hands are wet.**
- **Remove the plug from the socket by gripping the plug and not the cord.**

4. DESCRIPTION OF CONTROLS

4.1 CONTROL PANEL

All the commands and controls of the appliance are assembled together on the front panel.



Description of controls

A	**Open door** button
B	**ON-OFF and programme selection** knob
C	**Delay timer shown** on display LED **– (only for models with this option)**
D	**Time remaining** shown on display LED
E	**Spin speed** shown on display LED
F	**Drying programme for normal garments** shown on display LED
G	**Drying programme for delicates** shown on display LED
H	Display
I	**Select spin speed and drying time for delicates** button
L	**Drying programme** button **(automatic or timed)** and **drying time**
M	**Options** button – f**or models with delay timer: selection of time delay**
N	**Options** buttons
O	**Start-Pause** button
P	**Timed drying** shown on display LED
Q	**Automatic drying activation** with humidity sensor shown on display LED
R	Button activation and Start-Pause shown on LED

A	**Open door button**	Press the button to **open the door**. Chapter 5 – Washing instructions – explains how the door works and how to use it.
B	**ON-OFF and washing and drying programme selection knob**	This knob lets you: • switch the machine on and off by moving it in either direction from the **OFF** position (knob indicator vertical) • select **washing temperatures** within the various fabric **sectors** by turning it in both directions • select the **drying programme** The knob does not rotate while the programme is running. The programme is electronically controlled by the machine.
C	**Delay timer shown on display LED –** (only for models with this option)	This LED indicates that the display is showing the time selected for the delay timer.
D	**Time remaining shown on display LED**	This LED indicates that the display is showing the total duration of the selected programme before the programme starts, and the time remaining while the programme is running.
E	**Spin speed shown on display LED**	This LED indicates that the display is showing the maximum spin speed for the selected programme. It stays on while spin speed is being selected with the relative button.
F	**Drying programme for normal garments shown on display LED**	This LED indicates the selection of the normal drying programme (**drying temperature 90°C – for resistant items, cottons).**
G	**Drying programme for delicates shown on display LED**	This LED indicates the selection of the delicate drying programme (**drying temperature 60°C – for synthetics, delicates).**
H	**Display**	The display shows the following information: 1. **time remaining** for the selected programme, given in hours/minutes. 2. **delayed start** (for models featuring this option). Given in hours/minutes. When the time remaining before the programme starts is less than 60 minutes, this information is given in minutes/seconds. 3. **spin speed** 4. **drying times** given in hours/minutes 5. **cycle pause** - flashing STOP 6. **end of cycle** - END 7. **error codes** 8. **automatic drying programme (Aut1 or Aut2)**

I	**Select spin speed and drying time for delicates button**	Press the button repeatedly to select the required spin speed. The following spin speeds are available: • 0000: spin disabled and stop with tub full. The machine does not perform the final spin and ends the washing programme with water in the tub. To drain the water, see the explanations shown in paragraph 5.13 • from 600 rpm to the maximum speed indicated for the model: for cotton and coloured programmes, speed increases by 100 rpm starting from 600 rpm up to the maximum speed indicated for the model • from 600 to 900 rpm: for synthetics, delicates and woollens programmes, speed increases by 100 rpm starting from 600 rpm up to 900 rpm. Also, select the delicates drying programme (see G).
L	**Drying programme button (automatic or timed) and drying time**	Press the button repeatedly to select the drying programme: **timed drying or automatic.** As regards the drying time, it ranges from 2:00 hours down to 0:00 hours. For automatic drying it is possible to select two levels of residual humidity at the end of the drying process: Aut1 and Aut2.
M **N**	**Options buttons**	The options that may be available on the washer dryer are shown below.
	Quick wash Button 	This button reduces the overall duration of the washing cycle. This option is used to wash small loads or less dirty washing in less time. The bleach stage is skipped when the Quick Wash button is pressed (for models with bleach function).
(M)	**Select delayed start button –** (only for models with this option) 	Press the button repeatedly to select the required time from that moment to start the washing/drying programme selected. The value set by the machine is 0 hours 0 minutes and, using the button, this value can be increased by 60 mins up to 12 hours and by 120 mins for the next 12 hours, up to 24 hours.
	Increase water button 	This washer dryer is programmed to use a certain quantity of water and consume a certain amount of power considered to be sufficient for a normal washing cycle. **Only press this button for specific requirements**, e.g.: for very delicate fabrics (curtains or wool). The water level for washing and rinsing rises and **power consumption for heating increases.**
	Easy-iron button 	This option reduces creasing on garments at the end of the programme. The machine performs a more delicate spin cycle and moves the garments at the end of the programme. Spin speed for all programmes is 600 rpm.

	Economy cycle button E.e	Press this button for cottons programmes, **the machine will perform an extended wash at 35°C (biological step) thereby offering good washing performance combined with power saving.** **The machine then continues the cycle at the selected temperature.** ***N.B.:*** Press the **economy cycle** button to obtain a maximum washing temperature of 60° C and the elimination of the pre wash cycle.
	Extra Rinse button 	In areas with soft water or to improve rinsing, press this button (optional for intensive programmes) to enable the extra rinse function (about 20% more water).
	Delicates button 	Press this button to reduce movement of the drum and, consequently, of the washing. Suitable for particularly delicate garments (shirts, silk, curtains, etc.)
	Half load button 1/2	If the machine is used with a smaller amount of washing than that indicated in the “Programme Chart”, press this button to save water, detergent and electricity. This option should not be used for synthetics or woollens. **The recommended doses of detergents should be reduced in proportion to the load.**
O	**“Start/Pause” button** 	Press this button to start the selected washing programme. During washing, press the “Start/Pause” button for about 3 seconds to pause the washing cycle. During the pause, the “Time remaining” Led flashes and STOP appears on the display. To resume the washing cycle from where it left off, simply press the “Start/Pause” button again.
P	**Timed drying shown on display LED**	This LED indicates that drying is carried out with the selected drying time.
Q	**Automatic drying activation with humidity sensor shown on display LED**	This LED indicates that drying is carried out automatically with the selection of the required residual humidity level (Aut1 or Aut2)
R	**Button activation shown on LED**	This LED indicates that the corresponding buttons have been pressed.

4.2 DETERGENT TRAY

This is located to the left of the control panel. Pull it out to open.
The tray comprises four compartments which are marked as follows
"**1**": pre-wash detergent
"2": main wash detergent
"❀" or **"3"**: fabric softener, starch, etc. (treatment products).
Compartment **"4"** is used for bleach. If there is a cover marked ⛔, this means that bleach cannot be used with this model of machine. If bleach can be used with the machine, there is no cover.



5. WASHING INSTRUCTIONS

5.1 PREPARING THE WASHING

1. Separate the washing according to the type and colourfastness of the fabrics.
2. Wash whites and coloureds separately. Wash new coloured garments separately for the first time. A label is normally applied to garments giving information on how to clean them. A brief description of these labels is shown below.

WASHING		BLEACHING			
90	Machine wash at max. 90°C	Cl Bleaching allowed		Do not bleach	
60	Machine wash at max. 60°C				
		IRONING			
40	Machine wash at max. 40°C	Hot iron	Warm iron	Cool iron	Do not iron
30	Machine wash at max. 30°C				
		DRY CLEANING			
60	Machine wash, delicate cycle at max. 60°C	A Any solvent	P Any solvent except trichloroethylene	F Petroleum solvent and R113	Do not dry clean
40	Machine wash, delicate cycle at max. 40°C				
30	Machine wash, delicate cycle at max. 30°C				
		DRYING			
	Hand wash	High temperature	Less than 60°C		Do not tumble dry
	Do not wash				

Attention!

- Do not wash unhemmed or torn garments as they may fray.
- Foreign bodies may damage garments or machine components. Therefore, empty all pockets and turn them inside out, remove rollers from curtains or put them in a string bag.
- Put very small articles (belts, handkerchiefs, socks, bras with stiffeners, etc.) into a white canvas bag. Close push buttons and zips and sew on dangling buttons.
- Modern detergents and correct washing temperatures are generally sufficient to remove stains from fabrics. However, some stubborn stains, such as grass, fruit, egg, blood, rust and biro, should be pre-treated before washing. **Depending on the type of fabric, many stain removers can be found in the shops. Stains should always be cleaned or diluted immediately as the older they get, the more difficult they are to remove.**
- **Garments may be damaged if fabric care symbols are not observed.**

Wool – Only pure wool, identified by or with the label <<shrink-proof machine washable and dryable>> can be machine washed with the specific programme, other types of wool should be hand-washed or dry-cleaned.

5.2 OPENING THE DOOR

The machine is fitted with a safety device that prevents the door from opening while it is working.

1. **Before opening the door, wait 1 or 2 minutes after the programme ends ("End" LED on)** to allow the safety device to disengage.
2. **Make sure there is no water in the tub and that the drum is not moving.** Open the door by pressing the "Open door" button on the front panel and pulling it open.

Attention!

- If the washing programme is interrupted, you will have to wait from 3 to 15 minutes, depending on the temperature of the water, before the door opens.

Attention!
The water may still be boiling if the washing cycle was performed at high temperatures.
If there is still water inside the drum, do not open the door!

5.3 PREPARING THE WASHING

Where possible, **save electricity by washing full loads divided by type of fabric**. Introduce loose washing and alternate large items with small ones. For the first few times, weigh the loads of washing and then rely on your judgement. Average weights of common garments are shown below:

5.4 LOADING THE WASHING

1. Open the door and load the washing taking care to distribute it uniformly, loosely and not packed into the drum; alternate large items with small ones if possible.
2. The washer dryer described in this manual can be **loaded with up to 5kg** of washing. Heavier loads will lead to unsatisfactory washing results and may cause the machine to work incorrectly.
3. **To save energy, wash full loads** divided by type of fabric, according to the quantities indicated in the "Programmes chart" supplied with this manual.
4. Close the door by pressing it against the body of the appliance until you hear a click. Make sure no garments have got caught between the door and the rubber gasket.

Attention!

- If the door is not closed properly, a safety device prevents the washer dryer from working.
- **Do not use more than the recommended amount of detergent: too much may deteriorate washing results.**

5.5 ADDING DETERGENT AND ADDITIVES



Follow the instructions shown in the "Programme Chart" provided together with the manual and add detergent and any additives to the relative compartment before starting the programme.

Pour the pre-wash powder detergent into the compartment marked "**1**".

Pour main wash detergent into compartment "**2**". Machine accessories include a red insert **"A"** that can be placed inside compartment **"2"** to allow liquid detergent to be used. The additives are automatically introduced into the tub during final rinsing.
Pour liquid additives such as starch and fabric softener into "**3**", marked with .

If bleach can be used with the machine (no cover marked with) add bleach to compartment "**4**" if you wish.
The level of the liquids must not exceed the maximum limit, otherwise the trays will be emptied too soon.

Before pouring thick additives into the tray, dilute them with a little water to prevent them from obstructing the trap.

Only use foam-controlled detergent suitable for use in washer dryers.

Determine the quantity of detergent according to the hardness of the water, and the type, quantity and dirtiness of the washing.
This will allow you to obtain the required effect using as little detergent as possible.

Detergent packs indicate the quantities to use according to 4 levels of hardness and for normally dirty loads of 4-5 kg.
Ask your local water board to tell you how hard your water is.

Water hardness

Hardness level	*French degree fH*	*German degree dH*
Soft	Up to 15°	Up to 8°
Moderately hard	15° - 25°	8° - 14°
Hard	25° - 40°	14° - 22°
Very hard	Over 40°	Over 22°

5.6 DOSING POWDER DETERGENTS

Normally dirty washing
1. Choose a programme without prewash.
2. Pour the total quantity of detergent indicated on the packs into compartment “2” of the detergent tray.

Very dirty washing
1. Choose a programme with prewash.
2. Add ¼ of the recommended quantity of detergent into compartment “1” of the detergent tray and ¾ of the detergent into compartment “2”.

Attention!
- If there are no dosage indications for delicate synthetics, add from ½ to 2/3 of the recommended quantity for resistant cottons.
- For the wool programme, only use neutral detergents for woollens.
- Base your doses according to the detergent manufacturer's recommendations.

5.7 DOSING LIQUID DETERGENTS

1. Pour the recommended dose into the batcher supplied with the liquid detergent and place it inside the drum; otherwise, pour it into compartment “**2**” of the detergent tray after fitting the relative red insert “**A**” (see paragraph 5.5).
2. The scale on the red insert will help you to use the right quantity of liquid detergent.

Attention!
- Liquid detergents can be used according to the manufacturer's recommended dose **only for the main washing cycle, that is, in all programmes without prewash.**
- When compartment “2” is used for powder detergent, the red insert “A” must be removed.

5.8 SCALE-REMOVERS

Scale-removers can be introduced into compartments “**1**” and “**2**” according to the manufacturer's indications.
First, add the detergent and then the scale-remover.

5.9 SWITCHING ON THE MACHINE AND SELECTING THE WASHING PROGRAMME

To switch on the machine and select programmes, proceed as follows:

1. Turn the programme knob in either direction.
2. Select the washing temperature, within the sectors marked on the front panel by the following words:
   - ***Cotton, coloureds***
   - ***Wool***
   - ***Synthetics, delicates***

   The washer dryer has the following **basic washing programmes** which, by adjusting the temperature and using the various button functions, allow a wide range of programmes to be set for all requirements.

Intensive washing programme for resistant cotton, coloured or hemp fabrics.	
Delicate washing programmes for delicate artificial synthetic fibres, blends or linen fabrics. They prevent the formation of creases that are difficult to remove during ironing.	

Wool programme only for garments marked "pure wool" washable, treated, shrink proof. Other types of wool should be hand washed or dry-cleaned.	

To select programmes according to the type of fabric, consult the "Programme chart" supplied together with this manual.

Display information

When the machine is switched on, the display visualises the duration (hours/minutes) and maximum spin speed envisaged for the programme. These two parameters are displayed alternatively for 3 seconds each, together with their relative LED's, until the selected programme starts.



Attention!

- The following partial washing programmes can be set using the programmes knob:
  -Rinse with additive
  -Drain and spin
  -Fabric softener
  These partial programmes are inside the Cotton, Synthetics and Wool sectors, except for the drain and spin programme (Drain **)**.
- If the indicated temperature shows 0°, this means that the programme performs a cold wash cycle. The same cold wash is also performed by the **Hand wash** programme in the Wool sector.
- The fabric treatment labels show which washing temperature must be set.
- **If various garments in the same load require different washing temperatures, choose the lowest washing temperature of all.**
- If the laundry is only slightly dirty and does not need the bleaching effect of high temperatures, **a lower temperature can be chosen to save power.** In spite of the low temperature and consequent saving of electricity, an automatic time control keeps the duration of the main washing unvaried compared with that of a high temperature programme. It is therefore possible to successfully wash **normally dirty laundry at lower washing temperatures** than the maximum temperatures shown on the fabric care labels.

5.10 MODIFYING STARTING PARAMETERS

5.10.1 SPIN SPEED

Press the select spin speed button (), the relative LED lights up and the display visualises the maximum speed envisaged for the selected washing programme.
Press the button repeatedly. Speed decreases by 100 rpm every time until the spin cycle reaches 0 rpm and is disabled.



5.10.2 OPTIONS

Use the options buttons (indicated in chapter 4 – Description of controls, letter M) to enable machine options. A selected option is highlighted by the option LED located above the button in question.

5.10.3 DELAYED START (*ONLY FOR MODELS FEATURING THIS FUNCTION*)

Press the delayed start button (⏲). The relative LED located above the button lights up. The display visualises the time remaining (hours/minutes) before the selected washing programme starts: the display initially shows 0 hours 0 minutes for all programmes.



Press the button repeatedly. The Start delay increases by 30 minutes each time it is pressed for the first 12 hours. After that it increases to 60 minutes up to 24 hours.



While selecting the delayed start time, you can reset the timer by pressing the button for at least 3 seconds.

5.11 STARTING THE WASHING PROGRAMME

1. Before starting the selected programme, carefully close the door, open the water tap and add the detergent and additive
2. Press the “Start-Pause” button. The LED located above the Start-Pause button remains lit throughout the cycle.

After starting, the display shows the time remaining until the end of the programme. The LED remains on throughout the cycle.

Example



If delayed starting has been set (only for models featuring this option), the display visualises the time remaining before the cycle starts. When delayed starting is set, the relative LED flashes on and off.

Example



5.12 INTERRUPTING OR CHANGING THE WASHING PROGRAMME

The washing programme may be interrupted at any time while it is running:

1. press “Start/Pause” for approximately 3 seconds: the display alternates between STOP (for 1 second) and three horizontal lines (for 1 second) and the Start/Pause LED flashes.



The programme can also be stopped by turning the programme/temperature selection knob while the cycle is running.

2. If you wish to change the washing programme, simply select the new programme by turning the programme knob without pausing the machine first. The new washing cycle will be performed starting from the beginning. If the tub is already full of water, the new programme will omit the filling phase.
3. To resume the cycle, press Start-Pause again.

5.13 END OF PROGRAMME



The washing programmes are automatically completed, the display shows END and the "Time remaining" LED lights up.

1. **Turn the programmes knob to OFF to switch off the machine.**
2. Open the door.
3. Remove the washing from the drum.
4. Leave the door ajar in order to allow the inside of the washer dryer to dry.
5. **Turn off the water tap.**

If the no-spin option was selected during the initial spin speed set up phase and the machine stops with the tub full (spin speed 0), STOP appears on the display at the end of the washing programme, alternating with 0000 (spin speed 0) and the spin LED lights up.



To continue draining and spinning, press the spin select button twice. The machine resumes the cycle by draining the water and spinning. To select spin speed, press the button until the required speed is displayed. If you wish to drain the water in the tub without spinning, press the spin select button until 0000 appears on the display. This indicates that the machine will drain the water without spinning.

5.14 END OF PROGRAMME BEEPER

When a washing and/or drying cycle finishes, the message END appears on the display and a beepers sounds twice. To disable this signal, press the second and third button from the left simultaneously. The message OFF immediately appears on the display to indicate that the beeper has been disabled.



To enable the end of programme beeper, repeat the operation. This time, the message ON will appear on the display.



The appliance is supplied with the end of programme beeper enabled.

6. USING THE MACHINE FOR DRYING PURPOSES

6.1 GENERAL INFORMATION

During drying cycles it is essential that the water tap is open and that the drain hose is correctly positioned.
With this machine it is possible to set wash-only programmes, dry-only programmes and wash-dry programmes.
For the latter programmes, the cycle shifts automatically from washing to drying without the controls being touched and the cycle continues after washing.

Warnings

- Only dry linen or garments washed in a water-based solution and suitable for tumble drying.
-
- **The quantity of washing that can be introduced into the washer dryer for drying must not exceed 2.5kg.** This washer dryer has been built to offer maximum performance with dry loads weighing not more than 2.5 kg.
- When intensive washing programmes are set, drying is automatically performed at 90°C (normal drying).
- For delicate programmes, drying is automatically performed at 60°C (delicate drying). Therefore, for an automatic washing programme plus drying, the drying programme is dictated by the washing programme selected.
- In order to carry out a dry-only programme, the linen must already have been washed and spun.
- After drying particularly soft linen, e.g. new towelling underwear, it is advisable to carry out the “Rinse” programme in order to ensure that any small fabric deposits are drained away and are not deposited on the linen in the next wash load.

Important – do not dry delicate fabrics that cannot withstand temperatures of 60°C or in any case fabrics that cannot withstand the selected temperatures.

6.1.1 TABLE OF APPROXIMATE DRYING TIMES AND TEMPERATURES

Weight of washing	Resistant fabric drying at 90°	Delicate fabric drying at 60°	Drying result
1,5kg	40 minutes	80 minutes	Damp for ironing
	80 minutes	100 minutes	Dry
2.5kg	80 minutes	120 minutes	Damp for ironing
	100 minutes	-	Dry

6.1.2 EXTRA DRYING

If the washing is still too wet when the programme finishes, set a short timed drying cycle.
Caution! Do not dry garments too much as they may crease or shrink.

6.2 AUTOMATIC DRYING

During the drying cycle, the sensor senses the residual humidity. The length of drying time is adjusted according to the weight and type of washing. During the drying cycle the display shows the variations in the length of drying time. With automatic drying it is possible to select **2 levels of residual humidity at the end of drying.**

Aut1 **Normal dry** – suitable for thinner and normal fabrics.
Weight: 1.5 – 2.5kg
Aut2 **Extra dry** – suitable for thicker, heaver fabrics.
Weight: 1.5 – 2.5kg

6.2.1 Display messages if the weight is not appropriate

LO **Weight is too low** – the programme stops after 44 minutes in order to avoid ruining the washing.

HI **Weight is too high** – the programme carries out the drying for a maximum of the following times:

	Normal drying programme (length in hrs and mins)	Delicate drying programme (length in hrs and mins)
Aut1	1:50	1:50
Aut2	2:30	2:00

6.3 TIMED DRYING

The length of drying time corresponds to the time selected with the drying selection button.

6.4 WASH-DRY PROGRAMME

It is possible to use a wash-dry programme for intensive programmes (cotton, coloureds) and for synthetics/delicates. With the wool wash programme it is not possible to select automatic drying after washing.
To automatically wash and dry the washing, its weight **must not exceed 2.5kg for cotton or 1.5kg for synthetics**.
Therefore, if the weight of washing to be washed and dried exceeds the above limits, it is not advisable to carry out a wash-dry programme as, at the end, it will be necessary to half the load and carry out the drying process in two halves.
To carry out a **wash-dry programme**, follow the following steps:

1. Select the **wash programme** as indicated in paragraph 5.9;
2. Select the required spin speed as indicated in paragraph 5.10.1;
3. Press the select drying programme and times button **(button L)** to set the required drying programme:

(Automatic drying) **Auto** LED display showing: once the automatic drying programme has been selected (Aut1 or Aut2), the sensor inside the machine independently establishes the drying time. After about 5 seconds the programme setting closes and the value set is shown.

Time LED display showing: With this programme it is sufficient to repeatedly press the button to select the required drying time. After about 5 seconds the programme setting closes and the value set is shown. The drying time can be anything from 2:00 hours to 0:00 hours.

During the selection of the drying programme (automatic or timed) the **LED of the normal drying programme stays on**. This programme indicates an intense drying cycle and is meant for resistant items and cottons.
If a **delicate drying cycle** is required (less intensive drying, suitable for delicates and synthetics), press the Delicate Drying button. In this case the delicate drying programme LED is shown.

After selecting a drying programme (normal or delicate), press the Drying selection button within 5 seconds.

6.6 DRY-ONLY PROGRAMME

After a washing cycle has finished, follow the following steps to program a drying cycle:

1. Switch off the machine by turning the select washing/drying programme knob to OFF.
2. Position the knob on the drying program indicated with the symbol ✺;
3. Repeatedly press the select drying button (button L) until the programme is set (Automatic or timed). If you wish to reduce the drying temperature, press the Delicate Drying button.
4. Press the “Start-Pause” button to start the drying programme. The display shows the time remaining.

Warnings

- As there has been no washing cycle selected, the selection of the programme for drying (normal or delicate) is totally free. Remember that normal drying is advisable for cottons and coloureds, whereas delicate drying is advisable for synthetics and delicates.

- In order to obtain good drying results, the weight of the washing **must not exceed** 2.5kg for cotton or 1.5kg for synthetics.

6.5 INTERRUPTION OR CHANGE OF DRYING PROGRAMME

1. For the interruption or change of the drying programme, follow the instructions indicated in paragraph 5.12 – interruption or change of washing programme. When the machine is paused, it is possible to change drying programme and/or times by pressing the select drying button.
2. If you need to stop the programme and take out the linen, it is advisable to cool the linen down first. Using the select button, set the drying time to 20 minutes. Restart the machine as indicated in the following point and at the end it is possible to take out the linen.

7. CLEANING AND MAINTENANCE

Important – Before cleaning or servicing the machine, remove the plug from the socket.

7.1 EXTERNAL CLEANING

- Regular and constant cleaning will keep your appliance looking like new.
- Clean the unit with specific products for steel and dry thoroughly with a soft cloth.
- Clean parts in plastic with a damp cloth.
- Do not scratch with sharp objects and do not use solvents or abrasive products as these will damage the surface.
- **For reasons of safety, never spray water onto the appliance.**

7.2 CLEANING THE DRUM

- Remove any rust stains from the drum with a special cleaner for stainless steel or, for particularly stubborn stains, with extra fine abrasive paper.
- To remove scale from the washer dryer, only use branded scale removers with anti-corrosion agents for washing machines.
- Follow the manufacturer's instructions and recommended quantities to the letter.
- **After removing scale or rust from the drum, perform a few rinse cycles to eliminate acid residues as these may damage the machine. Never use detergents containing solvents. These may form vapours that may catch fire and explode.**

7.3 CLEANING THE DOOR GASKET

Periodically check that no clips, buttons, nails or needles have got caught in the folds of the door gasket.



7.4 CLEANING THE DRAIN PUMP

Only clean the drain pump if it is obstructed by buttons, hairpins and the like and the water cannot drain.
In this case, proceed as follows.

1. **Remove the plug from the socket to disconnect the machine from the electrical power supply.**

2. Pull out the base plate. To do this, put your hands underneath and lever it out.

3. Pull out the drain hose “A”.
   Attention: if the hose is hot it means the water is hot or boiling. Place a tray on the floor and remove the plug “B” to drain the water.
   Depending on the quantity of water, it may be necessary to empty the tray several times.
   When no more water comes out, push the hose back in and screw back the plug “B”.



4. Unscrew the screw “G” with a screwdriver and remove the metal plate “F” which prevents the pump cover “D” from turning.
   Unscrew the pump cover “D” by turning it anti-clockwise.
   Clean the pump body and remove any foreign bodies.
   Check the inside “E” and make sure the impeller turns freely. If there are any foreign bodies, remove them.







5. Then screw the pump cover back on.
   Position the metal plate “F” so that it prevents the cover from turning and tighten screw “G” with a screwdriver.
   Fix the drain hose by snapping the plug into place «C».
   Insert the lower part of the base plate first and then push it towards the unit until it clicks into place.



7.5 CLEANING THE DETERGENT TRAY

Keep the detergent tray free from scale.
To simplify this operation, completely remove the detergent tray (pull it out as far as it will go, lift it slightly and then pull fairly vigorously).

Remove the traps «B» (there are two traps if the machine is not fitted with a cover for the bleach compartment) and clean with hot water.
Put back the traps and remove any residues of detergent before putting the tray back.



7.6 CLEANING THE WATER INLET FILTER



The machine is fitted with a filter for protecting the water inlet valves.

The filter is fitted the gas thread of the inlet hose connected to the tap

Clean the filter if no water or insufficient quantities of water enter the washer dryer.
To do this, proceed as follows:

- **Remove the plug from the socket to disconnect the machine from the electrical power supply.**
- Turn off the water tap.
- Unscrew the inlet hose from the tap.
- Remove the filter from the inlet hose gas thread.
- Clean the filter with water and a brush.
- When screwing the inlet hose back on to the tap, make sure the filter is correctly positioned.

8. TROUBLESHOOTING

This product complies with current safety regulations governing electrical equipment. For safety reasons, all technical inspections or repairs must be performed by qualified technicians in order to prevent hazardous situations for users.

If the machine does not work, before calling the Service Centre and spending money unnecessarily, check that the operations indicated in this troubleshooting table have been performed.

1	**The machine does not start**	Check that: - the plug is correctly fitted into the socket - the door is securely closed - the “Start-Pause” button has been pressed.
2	**The tub does not fill with water**	Check that: - the plug is correctly fitted into the socket - the door is securely closed - the water tap is open - the water inlet filters are not clogged. Clean them as indicated in paragraph 6.5. - the water inlet tube is not jammed or bent
3	**No water appears to be in the drum**	No fault. The water level is lower than the glass of the door because the new machines use less water though obtaining the same washing and rinsing results.
4	**The water does not drain**	Check that: - the drain hose is not twisted - the drain pump is not clogged. Clean it as indicated in paragraph 6.3.
5	**The water does not drain after final rinsing in delicates and woollens washing programmes**	This is envisaged by the washing programme (if the no-spin and stop with tub full option has been selected) to prevent fabrics from creasing. To drain the water, proceed as described in the “End of programme” section, paragraph 5.13.
6	**The machine fills with water and drains continuously**	Make sure the end of the drain hose is not too low.
7	**Strong vibrations during spinning**	Check that: - the machine has been properly levelled as described in paragraph 3.2 - the machine is not too close to walls or furniture - the internal moving assembly has been released as described in paragraph 3.1
8	**Too much foam forms and escapes from the tray**	Check that: - the detergent is suitable for automatic machines and is not for hand washing - no more than the quantities indicated in the manual are used
9	**Water on the floor**	Check that: - the unions of the water inlet hose are not loose - the end of the drain hose has not moved out of place.
10	**Not all the fabric softener enters the machine or too much water remains in the compartment**	Make sure that the traps in the detergent tray are correctly positioned and are not clogged. Clean them as indicated in paragraph 6.4.

11	**The machine does not spin**	The unbalanced load sensor has triggered because the washing is not uniformly distributed inside the drum. If the washing is wet at the end of the cycle, distribute it well inside the basket and repeat just the spin cycle.
12	**Draining water from the drum**	In the event of a power failure or a fault in the appliance, the water inside the drum can be drained as described in paragraph 6.3
13	**The washing has not been correctly spun**	Large items have rolled up and are not uniformly distributed inside the drum. Always wash large items together with small ones.
14	**Residues of detergent on the washing**	Many phosphate-free detergents contain substances that are difficult to dissolve in water. Select the Rinse programme or brush the washing.
15	**The washing does not dry**	Check that: - the water tap is open - the washing does not weight too much - the drying time is suitable. - sufficient drying time has been selected If the machine does not dry all the same, call the Service Centre to remove fabric frays from the fan and drying ducts.
16	**Washing results are unsatisfactory**	- Too little detergent or an unsuitable detergent may have been used. - Stubborn stains were not pre-treated - The wrong temperature was selected - The drum was overloaded

ERROR SIGNALS

In the event of faults, the machine will display an error code.

Error code	*Problem*
	Door not closed properly. Close it.
	Aquastop. Contact the nearest Service Centre after disconnecting the machine from the electrical power supply and closing the water tap.
	No water for washing. See point 2 on the troubleshooting table.
	The water does not drain. See point 4 on the troubleshooting table.

For all other error codes, contact the nearest Assistance Centre after disconnecting the power supply and closing the water tap.

9. CONTROL PANEL SYMBOLS

PROGRAMS		OPTIONS		OTHER SYMBOLS	
	DRYING		WATER INCREASE		FABRIC CONDITIONER
	HAND WASH		NO SPIN OR STOP WHIT FULL TUB		OPEN DOOR
	PRE-WASH		DELAY TIMER		START-PAUSE
	RINSES		DELICATES		START
	DRAIN AND SPIN		ECONOMY CYCLE		WASH
SECTION			QUICK WASH		END
	COTTON AND COLOURED		EXTRA RINSE		HEATING
	WOOL		SPIN		TIME REMAINING
	DRYING		EASY-IRON		
	SINTHETICS AND DELICATES		HALF LOAD		